

Glendale Design Guidelines for Residential Buildings in Adopted Historic Districts

The Secretary of the Interior's Standards

Rehabilitation - is defined as the process of returning a property to a state of utility, through repair or alteration, which makes possible an efficient contemporary use while preserving those portions and features of the property which are significant to its historic, architectural, and cultural values. The following are the ten Rehabilitation Standards.

- (1) A property will be used as it was historically or be given a new use that requires minimal changes to its distinctive materials, features, spaces and spatial relationships.
- (2) The historic character of a property will be retained and preserved. The removal of distinctive materials or alteration of features, spaces and spatial relationships that characterize a property will be avoided.
- (3) Each property will be recognized as a physical record of its time, place, and use. Changes that create a false sense of historical development, such as adding conjectural features or elements from other historic properties, will not be undertaken.
- (4) Changes to a property that have acquired historic significance in their own right will be retained and preserved.
- (5) Distinctive materials, features, finishes, and construction techniques or examples of craftsmanship that characterize a historic property will be preserved.
- (6) Deteriorated historic features will be repaired rather than replaced. Where the severity of deterioration requires replacement of a distinctive feature, the new feature will match the old in design, color, texture, and where possible, materials. Replacement of missing features will be substantiated by documentary and physical evidence.
- (7) Chemical or physical treatments, if appropriate, will be undertaken using the gentlest means possible. Treatments that cause damage to historic properties will not be used.
- (8) Archaeological resources will be protected and preserved in place. If such resources must be disturbed, mitigation measures will be undertaken.
- (9) New additions, exterior alterations, or related new construction will not destroy historic materials and spatial relationships that characterize the property. The new work shall be differentiated from the old and will be compatible with the historic materials, features, size, scale, and proportion, and massing to protect the historic integrity of the property and its environment.
- (10) New additions and adjacent or related new construction will be undertaken in such a manner that, if removed in the future, the essential form and integrity of the historic property and its environment would be unimpaired.

Glendale Design Guidelines for Residential Buildings in Adopted Historic Districts

appendix one



Tudor Style home in Rossmoyne.